



Whats happening in `tcnt0_volatile.c`?

HARDWARE Timer tcnt0



Software Timer "ext-count"

MAIN:



Software timers are used to extend the range of hardware timers.